COOKTOP PARTS

For Model: SF315PEPW3, SF315PEPT3, SF315PEPB3
(White) (Designer Biscuit) (Black)

30" GAS FREESTANDING
STANDARD CLEAN RANGE
ELECTRONIC IGNITION



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	98014966	Instructions Installation
	98015589	Installation Instr (Template)
	98017489	Guide, Use & Care
	98007130	Safer Cooking Tips
	98016354	Tech Sheet
2		Cooktop
	98009677	White
	98009678	Biscuit
	98009676	Black
3		Panel, Manifold
	98009460	Black
	98009459	Biscuit
4		Knob, Burner (4)
	98006100	Black
	98008208	Biscuit
6	98009286	Grate, Burner (2)
7	98004722	Clip, Cooktop (2)
8	98014544	Wire, Ground
9	98013389	Bumper, Cooktop
10	98005000	Screw (3)
11	98014946	Cap, Burner
12	8534079	Screw
13	98009721	Grate, Center
14	98007225	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BACKGUARD PARTS

For Model: SF315PEPW3, SF315PEPT3, SF315PEPB3

(White) (Designer Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	98004632	Black Left
	98004633	Black Right
	98008274	Biscuit Left
	98008275	Biscuit Right
2	98006083	Rear, Backguard

Illus. No.	Part No.	DESCRIPTION
3		Swtich, Rocker
	98006392	Black
	98008276	Biscuit
4		Panel, Backguard
	98013424B	Black
	98013424T	Biscuit

Illus. No.	Part No.	DESCRIPTION
5		Control, Elec
	6610444	Black
	6610446	Biscuit
7	98015526	Screw
8	98004219	Screw
9		Bracket, Timer
	98008499	Left
	98008498	Right

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Model: SF315PEPW3, SF315PEPT3, SF315PEPB3

(White) (Designer Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Model: SF315PEPW3, SF315PEPT3, SF315PEPB3
(White) (Designer Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Burner, Top
	98008971	Left
	98003939	Right
2	98005860	Venturi, Front (2)
3	98005500	Brkt., Venturi (4)
4	98005862	Venturi, Rear (2)
5	6610341	Spark Module
6	98007411	Regulator
7	98007192	Cover, Module
8	98015099	Spreader, Flame
9	98006632	Screw
10	98012138	Burner, Oven
11	98006633	Screw
12	98014545	Harness, Switch
13	98014893	Valve, Oven
14	98006633	Screw
15		Valve, Burner (4)
	98005574	9,500 BTU
	98005626	11,500 BTU
16	98005521	Bolt, Valve Mtg
17	98013574	Pipe, Manifold
18	98009179	U−Nut
21	98005652	Igniter, Oven Oven Pilot)
22	98007132	Washer, Valve (4)
23	98007428	Tubing (Regltr to Oven Valve)
24	98013314	Locator, Burner
25	98007410	Bracket, Regulator
26	98007431	Fitting 3/8to9/16
27	98013634	Screw
28	1180823	Screw
31	98007429	Tubing, Inlet
32	98007430	Fitting 1/4to9/16
34	98005659	Screw
35	98004484	Screw
36		Igniter, Top
	98014514	RF
	98014515	RR
	98014521	LF
	98014522	LR
37	98015032	Clip, Igniter

FOLLOWING PARTS NOT ILLUSTRATED

98013676	LP Orifice Kit (For Use With LP)
98013677	Nat Orifice Kit (For use with Natural Gas)

CHASSIS PARTS

For Model: SF315PEPW3, SF315PEPT3, SF315PEPB3

(White) (Designer Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: SF315PEPW3, SF315PEPT3, SF315PEPB3
(White) (Designer Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	98003799	Flue Box
2	98013690	Clip, Flue
3	98014398	Shield, Insulation
4		Panel, Side (2)
	98010042	White
	98010045	Biscuit
	98010043	Black
5	98005502	Clip, Oven Bottom
6	98006710	Counterweight
7	98006739	Wire, Brick
8	98005044	Frame, Front
9	98005306	Foot, Front (2)
10	9761935	Foot, Rear (2)
11	98004449	Bottom, Oven
12	98015683	Baffle, Side (2)
13	98003847	Baffle, Base
14	98003830	Rail, Base (2)
15	98012175	Support, Burner
18	98009179	U−Nut
19	98005765	Switch, Door
20	98015100	Back, Main
21	98017163	Seal, Oven
22	98006633	Screw
23	98007193	Washer
24	98007126	Base, Foot
25	98006632	Screw
26	98006715	Shield, Channel
27	98007191	Shield, Lower
29	98014532	Cord, Power
30	98005026	Clip, Tubing
31	98015346	Foil, Side (2)
32	98006634	Screw
33	98004447	Top, Oven
34		Side, Oven
	98004452	Right Hand
	98004451	Left Hand
35	98013777	Back, Oven
36	98015363	Support, Rear
37	98004498	Bulb, Light
38	98004293	Socket, Light
40	98007205	Cap, Insulation
41	8273902	Sensor, Oven
42	98014105	Cover, Valve
43	98014104	Cover, Socket

INSULATION

98014360	Insulation, Wrap
98004286	Insulation, Back

OVEN & BROILER PARTS

For Model: SF315PEPW3, SF315PEPT3, SF315PEPB3
(White) (Designer Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	98014136	Rack, Oven (2)
2	98003480	Grill, Broiler
3	98016005	Pan, Broiler
4	98016571	Rack, Broiler
5	98005296	Bracket, Rack
6		Guide, Fixed(2)
	98004994	Left
	98005209	Right
7		Guide, Mobile(2)
	98004995	Left
	98004954	Right

Illus. No.	Part No.	DESCRIPTION
8		Screw
	98006727	White
	98008169	Biscuit
	98006726	Black
9	98004991	Liner, Door
10	98015096	Storage, Drawer
11	98015234	Insulation, Door
12		Panel, Door
	98009337	White
	98009336	Biscuit
	98009338	Black

Illus. No.	Part No.	DESCRIPTION
13		Handle, Brlr Door
	98006623	White
	98008266	Biscuit
	98006624	Black
14	98004773	Spacer, Handle
15	98004052	Bumper, Door(2)
17	98005295	Support, Rack
20	98004219	Screw
21	98006644	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: SF315PEPW3, SF315PEPT3, SF315PEPB3
(White) (Designer Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	8533841	Screw
3	98010182	Liner, Door
4	98006753	Insulation, Door
5		Clip, Glass
	98004952	Left
	98004953	Right
6	98004734	Hinge, Door (2)
8		Panel, Door
	98017234B	Black
	98017234T	Biscuit
9	98006801	Glass, Inner
10		Handle, Oven Door
	98016237B	Black
	98016237T	Biscuit
11	98010557	Actuator (2)
12	98004993	Screw
13		Side Trim, Door(2)
	98016787B	Black Left
	98016795B	Black Right
	98016787T	Biscuit Left
	98016795T	Biscuit Right
14		Screw
	98008545	Black
	98008169	Biscuit
15		Retainer
	98004564	Right
	98004629	Left
16		Lower Trim, Door
	98010187	Black
	98010184	Biscuit
17	98004219	Screw
18	98004227	Bumper
19	98004938	Insulation, Retainer−Top
20	98012904	Insulation, Retainer−Bottom
21	98017250	Retainer, Upper

OPTIONAL PARTS

For Model: SF315PEPW3, SF315PEPT3, SF315PEPB3
(White) (Designer Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

SPLICING WIRES−−25FT. LENGTH

242828	Wire, Black 12 Ga. 150° c
8316781	Wire, Black 14 Ga. 150°c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242827	Wire, Yellow 14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch−Up Self−Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
240132	Insulation, Fiberglass (2−1/2" x 22" x 120")

PAINT, TOUCH−UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

WIRING HARNESS PARTS

6610436	Harness, Control
98005896	Clip, Wire
3196696	Clip, Wire
3391018	Cable Tie−Push Mnt
98015022	Bushing, Snap (2)
98005894	Clamp, Cord

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

ANTI−TIP KIT

98017833	Anti−Tip Kit

Miscellaneous

814381	Pin Kit−Dr Removal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST